

K5TIT – Texas Interconnect Team

Setup ID-1 for Data Operations to the Internet

Open the CS window

YOUR Enter the call sign of the repeater
(UR) Example K5TIT

REPEATER

RPT1 Enter the call sign of the repeater
Example K5TIT**A

The * is a space.

RPT2 Enter the call sign of the repeater and click the G button
This will put the G on the end of the call for you.
Example K5TIT**G

MY This is the call sign in the Gateway system.
Example N5ZPR or N5ZPR**B

You must use the correct call sign/IP combination

Example	Radio 1	N5ZPR	10.##.98
	Radio 2	N5ZPR**B	10.##.99
	Radio 3	N5ZPR**C	10.##.100

The * is a space.

Computer Setup

The computer used with the radio must have the fixed IP address assigned to the call sign.

IP	Assigned Address
Netmask	255.0.0.0
GW	10.0.0.1
DNS	10.0.0.1