

K5TIT – Texas Interconnect Team

Setup ID-1 for Data Operations Direct User to User

This can only be done as point to point. If you want or need more than two radios you must use the RP2-D.

Select a common frequency with the other user.

Set the mode to DD

Open the CS window

YOUR Enter the call sign of the other user's radio
(UR) Example N5MIJ

REPEATER

RPT1 Not used in this mode

RPT2 Not used in this mode

MY This is the call sign you wish to use
Example N5ZPR or N5ZPR**B

Computer Setup

The computer used with the radio must have an IP address in the same subnet to communicate with the other system.

Note: Remember if you are using Windows 2000 or XP you will need to deal with the security and user authentication in your systems.